Important Magic Mat Information

1 message

Scrapbook.com <jilld@scrapbook.com> Wed, Nov 11, 2020 at 5:05 PM
To:

Scrapbook.com

magic mat™ information

Thank you so much for your recent purchase of the NEW Scrapbook.com Magic Mat! These went viral and sold out quickly - but you were able to get yours before they were gone! We have received a few questions and want to provide some clarification and tips:

- The Magic Mats are designed to replace (1) of the cutting pads used in your die cutting machine.

- The Magic Mats are designed to be the SAME size and thickness as the Sizzix Big Shot Cutting Plates (Standard and Extended sizes). *If Sizzix cutting plates do not currently work in your die cutting machine at home, then the Magic Mat may not work as well, or fit.*

- Machine Compatibility: With the correct “sandwich”, Magic Mats are compatible with these machines:
    - **Standard and Extended Magic Mat**: Sizzix Big Shot, Sizzix Big Shot Plus, Sizzix Big Shot Foldaway, Sizzix Big Shot Express, Spellbinders

Platinum, Spellbinders Platinum 6, Sizzix Tim Holtz Vagabond (1 and 2), Crafter’s Companion Gemini, We R Memory Keepers Revolution

- **Extended Magic Mat ONLY**: Crafter’s Companion Gemini Jr, Cuttlebug

- **Mini Magic Mat ONLY**: Crafter’s Companion Gemini Go, We R Memory Keepers Evolution Mini.

Magic Mats are not guaranteed to work in machines that are not on the list here. Some crafters have experimented and found ways to use Magic Mats in various other brands of die cutting machines, but we cannot guarantee their compatibility at this time until we have fully tested them.

- **Tips for using Magic Mat with aforementioned compatible machines:**
  - When replacing (1) cutting pad, use your magic mat as the cutting pad that your thin metal dies cut *into* (blade side cuts into the Magic Mat) and send through your die cutting machine.
  - The Magic Mat can be used facing up or down and should be flipped and rotated regularly to extend the use.
  - Ensure you're using the right "sandwich" set up for running through your die cutting machine.
  - If your cuts aren't deep enough, try adding paper or cardstock shims until you have the perfect cut.
  - If your die cutting machine has had many years of usage (and love!)....you may need to shim with paper/cardstock... each machine is a little different. Even the same models of machines can vary depending on how they were manufactured or from wear and tear.

- Scrapbook.com is currently testing and researching additional machines, including some that are out of production. We will send updates in the future.

- We will be sending links to additional videos with more details and instructions on how to create the perfect “sandwich” for each machine in the

coming weeks!

- If you have questions or problems, ***we want to hear from you***. Please reach out to customer service. Of course, if you are not satisfied, we offer a money back guarantee on **all** purchases from Scrapbook.com. We normally offer a 60-day money back guarantee, but we've extended it to 90 days on the Magic Mats to give you plenty of time to test it out and make sure you're satisfied.

Thank you again for your support and enthusiasm. We're here to serve you and empower your beautiful, meaningful, handmade creativity!

The Scrapbook.com Team

This email was sent to **luminaspirit@gmail.com** by **Scrapbook.com**
1495 E Baseline Rd | Gilbert | AZ | 85233
Update My Email Preferences | Unsubscribe From All